



YOUR NEW ZEALAND MANUFACTURED ORGANIC SOLUTION
TO A CLEAN GREEN ENVIRONMENT



Foamer Dual Chamber Industrial, Cleaner and Multipurpose

Foam nozzle
(Do not adjust the nozzle,
as it is already set at
the optimal position for
foaming application)

Squeeze trigger to
start foaming

Blue tab for warm
or cold water

1. Turn lever to unlock
bottle & remove by
sliding down.
2. Fill with water from
tap.
3. Push bottle back
up sliding up the
grooves.
4. Turn lever to lock
bottle in when
filled.



Fill with warm
or cold water
from tap.



Foamer
Dual
Chamber
when
filled.

Green tab for
Bio-Zyme Cleaner
Concentrate

1. Turn lever to unlock
bottle & remove by
sliding down.
2. Fill with Bio-Zyme
Concentrate shown
in the label as below.
3. Push bottle back
up sliding up the
grooves.
4. Turn lever to lock
bottle in when filled.



Fill Dual
Chamber
Bottle with
Bio-Zyme
Concentrate
accordingly to
the label. Use
pump
on 5L bottle.

Before using the Foamer Dual Chamber

- Check if the **Water** bottle is on the **blue tab**, and the **Bio-Zyme Concentrate** bottle on the **green tab**.
- Ensure bottles are locked in or they will fall out and/or spill.

Bio-Zyme NZ Ltd

88 Treffers Road, Wigram - Christchurch
0800 246 9963 | office@bio-zyme.co.nz | www.bio-zyme.co.nz